

hello plumber.

Installing concrete basins is a little different to ceramic. Please carefully read instructions prior to install to avoid any issues.

GENEROUSLY APPLY CLEAR SILICON WITHOUT GAPS:



around the waste



where the basin
meets the benchtop

24HRS

please allow silicon
24 hrs to dry
before
water testing

DO NOT

place tools, taps
and mixers in/near
basin during install
to avoid damage

**INSTALL VIDEO: [NOODCO.CO.AU/SINKS-INFO/#INSTALL](https://www.noodco.co.au/sinks-info/#install)
SUPPLIED WITH SINK: **BASIN INSTALLATION GUIDE****